

Ozroll ODS Control 10 Battery Replacement Instructions using non-genuine batteries.

These instructions detail the required procedure to replace the battery in all Ozroll Control 10 products (RF and Non RF).

These will be product's with part numbers 15.200.001, 15.202.001, 15.205.001, 15.206.001



Figure 1

1) Using the tool supplied remove the screw on the back panel of the controller.

2) Slide the back of the controller down (it will only move approximately 6mm). Refer to Figure 1.

3) Lift off the back of the controller to expose the battery.

4) Pull the bottom (connector end) of the battery upward to release the connector. The battery should come free, quite easily. Refer to Figure 2

5) Fit the new battery with the label facing upward. Slide the top of the new battery into place, and then fit the connector to the controller board, ensure the connector is a good fit.

6) Press the battery down so that it sits flat.

7) Refit the back panel of the controller, check it is in the correct position and slide it up into place. Press at the top of the back panel to guide the tip into position.

8) Refit the screw on the back panel, **being careful not to over tighten the screw.**




Figure 2

Before use charge the controller as normal allow the battery to fully charge. The red LED on the front of the controller will be Lit when the controller is charging.(charging may take from 5-8 hours).The red light indicates that the charger is working and the battery is accepting charge.

If the controller is not working property check the above instructions have all been followed correctly. If problems persist contact us at sales@millercanvas.com.au.

Product Warranty – Miller Canvas guarantees the battery for 12 months from date of purchase against any defect in material or workmanship under conditions of normal use and service.

Warranty Service Conditions – Miller Canvas expressly limits its liability with respect to its products to the person who purchases the product direct from Miller Canvas.

Miller Canvas expressly limits its liability with respect to its products to: [in the absolute discretion of Miller Canvas]

1. The cost of having the goods repaired
2. The cost of replacing the goods: or
3. The cost of obtaining equivalent goods.

In the event of the goods requiring service under warranty, the owner is responsible for the prepaid cost of appropriate transportation to the authorized service organization. Whilst in transit the goods are at the owner's risk. Should the goods be found to be in sound working order by the authorized service organization the owner may be charged a service fee.

The goods will not be eligible for service under this warranty if:

1. Proof of date of purchase cannot be provided.
2. The goods have been supplied to or used by a person other than the purchaser.
3. The defect was caused by an accident, misuse, abuse, improper installation or operation, lack of reasonable care and maintenance, unauthorized modification, loss of parts, tampering or attempted repair by a person not authorized by Miller Canvas.

Miller Canvas shall not be liable for any loss or damage arising from the purchase, use or inability to use this product or for any special, indirect, incidental or consequential damages. No other warranties express, or implied are made. Nothing in this warranty excludes, restricts or modifies any condition, warranty, right or liability implied or protected by law where to do so would render this warranty or any part of it void.